


# G52A

## QorIQ Enhanced Network CPU Board

### 3U CompactPCI Serial



User Manual



# Contents

<b>Contents</b> .....	<b>2</b>
<b>About this Document</b> .....	<b>5</b>
<b>Product Safety</b> .....	<b>7</b>
<b>Legal Information</b> .....	<b>8</b>
<b>1 Product Overview</b> .....	<b>10</b>
1.1 Product Description .....	10
1.2 External Interfaces .....	11
1.3 Board Layout .....	12
1.4 Block Diagram .....	13
1.5 Technical Data .....	14
1.6 Product Identification .....	16
<b>2 Getting Started</b> .....	<b>17</b>
2.1 Configuring the Hardware .....	17
2.1.1 microSD Card .....	17
2.2 Connecting and Starting .....	18
2.3 Troubleshooting at Start-up .....	18
2.4 Installing Operating System Software .....	19
2.5 Installing Driver Software .....	19
2.6 Using the G52A under Linux .....	19
2.6.1 Accessing Board Management Functions .....	19
<b>3 Functional Description</b> .....	<b>23</b>
3.1 Power Supply .....	23
3.2 Processor Core .....	23
3.2.1 Thermal Considerations .....	23
3.3 Supervision and Management .....	24
3.3.1 Watchdog .....	24
3.3.2 Temperature Measurement .....	24
3.3.3 Status LEDs .....	25
3.3.4 Software Support .....	26
3.4 Reset .....	27
3.5 Real-Time Clock (RTC) .....	27
3.6 Memory .....	28
3.6.1 DRAM System Memory .....	28
3.6.2 Boot Flash .....	28
3.7 Mass Storage .....	28
3.7.1 microSD Card .....	28
3.7.2 Serial ATA (SATA) .....	28
3.8 USB .....	29
3.8.1 Front Connection .....	29
3.8.2 Rear Connection .....	29
3.8.3 USB-to-UART Interface .....	29

3.9	Ethernet	30
3.9.1	Front Connection	30
3.9.2	Rear Connection	31
3.9.3	Signal Mnemonics	31
3.9.4	Ethernet MAC Addresses	32
3.9.5	Ethernet Status LEDs	33
3.10	PCI Express	34
3.11	CompactPCI Serial	34
3.11.1	Backplane Filling Order	34
3.11.2	Using the G52A as a Peripheral Board	36
<b>4</b>	<b>U-Boot Firmware</b>	<b>37</b>
4.1	General	37
4.2	Getting Started: Setting Up Your Operating System	37
4.3	Interacting with U-Boot	38
4.3.1	Setting Up a Console Connection	38
4.3.2	Entering the U-Boot Command Line	38
4.3.3	User Interface Basics	39
4.3.4	Booting an Operating System	42
4.4	U-Boot Images	43
4.4.1	Images	43
4.4.2	Updating U-Boot Image 1	44
4.5	Updating User Data in the Boot Flash	45
4.5.1	Update via Network	45
4.5.2	Update via Mass Storage Devices	45
4.5.3	Update via the Serial Console	45
4.5.4	Performing an Update	46
4.6	Diagnostic Tests	47
4.6.1	Power-On Self Tests	47
4.7	U-Boot Implementation on G52A	48
4.7.1	Boot Flash Memory Map	48
4.7.2	Environment Variables	48
4.7.3	U-Boot Commands	52
4.7.4	Hardware Interfaces Not Supported by U-Boot	52
<b>5</b>	<b>Hardware/Software Interface</b>	<b>53</b>
5.1	PCI Express Root Port Interrupt Mapping	53
5.2	I2C Devices	54
5.3	BMC API (Application Programming Interface)	55
5.3.1	BMC Command Packets	55
5.3.2	Example BMC API Usage	77
<b>6</b>	<b>Maintenance</b>	<b>78</b>
6.1	Optional Lithium Battery	78

**Figures**

Figure 1. Front interfaces .....11  
 Figure 2. Board layout – top view. ....12  
 Figure 3. Block diagram.....13  
 Figure 4. Product labels.....16  
 Figure 5. Position of optional lithium battery on G52A .....78

**Tables**

Table 1. General status LEDs.....25  
 Table 2. Error codes signaled by board management controller via LED flashes...25  
 Table 3. Hot-swap LED .....26  
 Table 4. Pin assignment - USB 2.0 .....29  
 Table 5. Signal mnemonics - USB 1.0/2.0 .....29  
 Table 6. Connector types – Ethernet M12 .....30  
 Table 7. Pin assignment – Ethernet (8-pin M12).....30  
 Table 8. Connector types – Ethernet (RJ45).....30  
 Table 9. Pin assignment – Ethernet (RJ45).....30  
 Table 10. Signal mnemonics – Ethernet.....31  
 Table 11. Ethernet MAC addresses.....32  
 Table 12. Ethernet status LEDs at front panel .....33  
 Table 13. CompactPCI Serial backplane filling order .....35  
 Table 14. U-Boot – Boot Flash memory map .....48  
 Table 15. U-Boot – Environment variables – OS boot .....48  
 Table 16. U-Boot – Environment variables – Network.....49  
 Table 17. U-Boot – Environment variables – Console .....50  
 Table 18. U-Boot – Environment variables – Other .....50  
 Table 19. U-Boot – G52A-specific commands .....52  
 Table 20. PCI Express Root Port Interrupt Mapping for Downstream Devices .....53  
 Table 21. I2C devices .....54  
 Table 22. BMC API – Packet types.....55  
 Table 23. BMC API – Packet types mapping on SMBus.....56  
 Table 24. BMC API – Watchdog commands.....56  
 Table 25. BMC API – Power resume mode commands .....58  
 Table 26. BMC API – Power resume modes .....58  
 Table 27. BMC API – External power supply failure mode commands .....60  
 Table 28. BMC API – Reset signal blocking commands .....61  
 Table 29. BMC API – External power supply control commands .....62  
 Table 30. BMC API – Software reset commands.....63  
 Table 31. BMC API – Power button commands .....64  
 Table 32. BMC API – Voltage supervision commands .....65  
 Table 33. BMC API – Error counters .....67  
 Table 34. BMC API – Error counter commands.....67  
 Table 35. BMC API – Firmware version commands .....69  
 Table 36. BMC API – Board controller mode command .....70  
 Table 37. BMC API – Backplane slot geographical address command .....71  
 Table 38. BMC API – Last error command.....72  
 Table 39. BMC API – Power failure flags command .....73  
 Table 40. BMC API – Reset reason command .....74  
 Table 41. BMC API – Clear error registers command.....75  
 Table 42. BMC API – Power cycle counter command.....75  
 Table 43. BMC API – Operating hours counter command .....76  
 Table 44. BMC API – Status LED control command .....77

## About this Document

This user manual is intended only for system developers and integrators, it is not intended for end users.

It describes the design, functions and connection of the product. The manual does not include detailed information on individual components (data sheets etc.).



G52A product page with up-to-date information and downloads:  
[www.men.de/products/g52a/](http://www.men.de/products/g52a/)

### History

Issue	Comments	Date
E1	First issue	2016-07-13
E2	General update, minor errors corrected	2017-03-22

## Conventions



Indicates important information or warnings concerning situations which could result in personal injury, or damage or destruction of the component.



Indicates important information concerning electrostatic discharge which could result in damage or destruction of the component.



Indicates important information or warnings concerning proper functionality of the product described in this document.



The globe icon indicates a **hyperlink** that links directly to the Internet. When no globe icon is present, the hyperlink links to specific information within this document.

*Italics* Folder, file and function names are printed in *italics*.

*Comment* Comments embedded into coding examples are shown in green text.

IRQ#  
/IRQ Signal names followed by a hashtag "#" or preceded by a forward slash "/" indicate that this signal is either active low or that it becomes active at a falling edge.

In/Out Signal directions in signal mnemonics tables generally refer to the corresponding board or component, "in" meaning "to the board or component", "out" meaning "from the board or component".

0xFF Hexadecimal numbers are preceded by "0x".

0b1111 Binary numbers are preceded by "0b".

## Product Safety

### Electrostatic Discharge (ESD)



Computer boards and components contain electrostatic sensitive devices. Electrostatic discharge (ESD) can damage components. To protect the PCB and other components against damage from static electricity, you should follow some precautions whenever you work on your computer.

- Power down and unplug your computer system when working on the inside.
- Hold components by the edges and try not to touch the IC chips, leads, or circuitry.
- Use a grounded wrist strap before handling computer components.
- Place components on a grounded antistatic pad or on the bag that came with the component whenever the components are separated from the system.
- Only store the product in its original ESD-protected packaging. Retain the original packaging in case you need to return the product to MEN for repair.

## Legal Information

### **Changes**

MEN Mikro Elektronik GmbH ("MEN") reserves the right to make changes without further notice to any products herein.

### **Warranty, Guarantee, Liability**

MEN makes no warranty, representation or guarantee of any kind regarding the suitability of its products for any particular purpose, nor does MEN assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including, without limitation, consequential or incidental damages. TO THE EXTENT APPLICABLE, SPECIFICALLY EXCLUDED ARE ANY IMPLIED WARRANTIES ARISING BY OPERATION OF LAW, CUSTOM OR USAGE, INCLUDING WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE OR USE. In no event shall MEN be liable for more than the contract price for the products in question. If buyer does not notify MEN in writing within the foregoing warranty period, MEN shall have no liability or obligation to buyer hereunder.

The publication is provided on the terms and understanding that:

1. MEN is not responsible for the results of any actions taken on the basis of information in the publication, nor for any error in or omission from the publication; and
2. MEN is not engaged in rendering technical or other advice or services.

MEN expressly disclaims all and any liability and responsibility to any person, whether a reader of the publication or not, in respect of anything, and of the consequences of anything, done or omitted to be done by any such person in reliance, whether wholly or partially, on the whole or any part of the contents of the publication.

### **Conditions for Use, Field of Application**

The correct function of MEN products in mission-critical and life-critical applications is limited to the environmental specification given for each product in the technical user manual. The correct function of MEN products under extended environmental conditions is limited to the individual requirement specification and subsequent validation documents for each product for the applicable use case and has to be agreed upon in writing by MEN and the customer. Should the customer purchase or use MEN products for any unintended or unauthorized application, the customer shall indemnify and hold MEN and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim or personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that MEN was negligent regarding the design or manufacture of the part. In no case is MEN liable for the correct function of the technical installation where MEN products are a part of.

### **Qualified Personnel**

The product/system described in this documentation may be operated only by personnel qualified for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.



## Conformity

MEN products are no ready-made products for end users. They are tested according to the standards given in the Technical Data and thus enable you to achieve certification of the product according to the standards applicable in your field of application.

## RoHS

Since July 1, 2006 all MEN standard products comply with RoHS legislation.

Since January 2005 the SMD and manual soldering processes at MEN have already been completely lead-free. Between June 2004 and June 30, 2006 MEN's selected component suppliers have changed delivery to RoHS-compliant parts. During this period any change and status was traceable through the MEN ERP system and the boards gradually became RoHS-compliant.

## WEEE Application



The WEEE directive does not apply to fixed industrial plants and tools. The compliance is the responsibility of the company which puts the product on the market, as defined in the directive; components and sub-assemblies are not subject to product compliance.

In other words: Since MEN does not deliver ready-made products to end users, the WEEE directive is not applicable for MEN. Users are nevertheless recommended to properly recycle all electronic boards which have passed their life cycle.

Nevertheless, MEN is registered as a manufacturer in Germany. The registration number can be provided on request.

Copyright © 2017 MEN Holding. All rights reserved.

### Germany

MEN Mikro Elektronik GmbH  
Neuwieder Straße 3-7  
90411 Nuremberg  
Phone +49-911-99 33 5-0

[info@men.de](mailto:info@men.de)  
[www.men.de](http://www.men.de)

### France

MEN Mikro Elektronik SAS  
18, rue René Cassin  
ZA de la Châtelaine  
74240 Gaillard  
Phone +33-450-955-312

[info@men-france.fr](mailto:info@men-france.fr)  
[www.men-france.fr](http://www.men-france.fr)

### USA

MEN Micro Inc.  
860 Penllyn Blue Bell Pike  
Blue Bell, PA 19422  
Phone 215-542-9575

[sales@menmicro.com](mailto:sales@menmicro.com)  
[www.menmicro.com](http://www.menmicro.com)

### China

MEN Mikro Elektronik  
(Shanghai) Co., Ltd.  
Room 808-809, Jiaying  
Mansion, No. 877 Dongfang  
Road  
200122 Shanghai  
Phone +86-21-5058-0961

[sales@men-china.cn](mailto:sales@men-china.cn)  
[www.men-china.cn](http://www.men-china.cn)

# 1 Product Overview

## 1.1 Product Description

### ***New Generation of CPU Boards***

The G52A is a high-performance multicore CPU platform based on NXP (formerly Freescale) QorIQ T4x series. The G52A is a new branch of CPU boards for CompactPCI Serial specifically designed for high data bandwidth based on PCIe 3.0, PCIe 2.0 and Gigabit Ethernet via the backplane. The G52A provides high data bandwidth on the front panel via two 10 Gigabit Ethernet interfaces on M12 connectors or on RJ45 connectors (on request). The G52A paired with I/O cards can be ideally used for transferring data from and to storage media, the Internet via LTE, WiFi, copper or optical Ethernet. Its up to 12 processor cores make the board ideally suited for virtualization applications. Serial interfaces at the rear I/O connectors are one USB 2.0, two SATA interfaces, three PCI Express x4 links and one PCI Express x2 link and three Gigabit Ethernet interfaces.

### ***Three-channel DDR3 DRAM***

The memory configuration of the G52A includes a fast DDR3 DRAM with ECC which is soldered to the board to guarantee optimum shock and vibration resistance. A microSD card device offers space for user applications or can be used as a local boot medium.

### ***Board Supervision***

The G52A features thermal supervision of the processor and a watchdog for the operating system.

### ***Perfect for Harsh Environments***


The G52A comes with a tailored heat sink within 4 HP height. All components are soldered for protection against shock and vibration according to applicable DIN, EN or IEC industry standards. The G52A is also ready for coating so that it can be used in humid and dusty environments and has a guaranteed minimum standard availability of 15 years. These features make the G52A perfectly suited for harsh environments.

### ***Software***

The G52A operates in Linux environments or as a development option in VxWorks or QNX environments.


### 1.2 External Interfaces

Figure 1. Front interfaces (M12 connectors on the left, RJ45 connectors on the right)




### 1.3 Board Layout

Figure 2. Board layout - top view



### 1.4 Block Diagram

Figure 3. Block diagram



## 1.5 Technical Data

### CPU

- The following CPU types are available:
  - NXP QorIQ T4240, twelve cores, 1.5 to 1.8 GHz
  - NXP QorIQ T4160, eight cores, 1.5 to 1.8 GHz (on request)
  - NXP QorIQ T4080, four cores, 1.5 to 1.667 GHz (on request)

### Memory

- System Memory
  - Soldered DDR3, ECC support
  - Up to 3 channels
  - 4 GB, 6 GB, 8 GB or 12 GB
- Boot Flash
  - 32 MB

### Mass Storage

- The following mass storage device can be assembled:
  - microSD card (up to 32 GB)

### Front Interfaces

- USB
  - One Series A connector, USB 2.0
  - One RS232 configuration port, USB 2.0
- Ethernet
  - Two 8-pin M12 connectors, X-coded, 10GBASE-T, or
  - Two RJ45 connectors, 10GBASE-T (option)
  - One 8-pin M12 connector, X-coded, 1000BASE-T, or
  - One RJ45 connector, 1000BASE-T (option)
  - One link and activity LED per Ethernet channel
- Front-panel LEDs for board status
- Hot-plug LED
- Reset button

### Rear Interfaces

- SATA
  - Two channels, SATA Revision 2.x
- USB
  - One channel, USB 2.0
- Ethernet
  - Three channels, 1000BASE-T
- PCI Express
  - Two x4 links, PCIe 2.x
  - One x2 link, PCIe 2.x
  - One x4 link, PCIe 3.x

**Supervision and Control**

- Board controller
- Watchdog timer
- Temperature measurement
- Real-time clock with supercapacitor or battery backup

**Backplane Standard**

- Compliance with CompactPCI Serial PICMG CPCI-S.0 Specification
- System or peripheral slot

**Electrical Specifications**

- Supply voltages
  - +12V (9.5..15.5V)
- Power consumption
  - The following values are valid for product model 02G052A00, which uses a T4240 processor.
  - +12V: 4 A nominal, 8 A maximum

**Mechanical Specifications**

- Dimensions
  - 3U, 4 HP
- Weight: approx. 266 g (model 02G052A00)

**Environmental Specifications**

- Temperature range (operation)
  - EN 50155 class T1, T2, T3 or TX
  - Airflow 2.5 m/s
  - Depends on system configuration (CPU, hard disk, heat sink...)
- Temperature range (storage): -40°C to +85°C
- Cooling concept
  - Air-cooled, or
  - Conduction-cooled in MEN CCA frame
- Humidity: EN 60068-2-30, EN 50155
- Altitude: -300 m to +3000 m
- Shock: EN 50155 cat 1 class b
- Vibration: EN 50155 cat 1 class b

### Safety

- Flammability
  - UL 94V-0
- Electrical Safety
  - EN 62368-1 (former EN 60950-1)

### EMC Conformity

- EN 55022 class B, EN 50121-3-2 (radiated and conducted emission)
- EN 55024, EN 50121-3-2 (immunity)

### BIOS

- U-Boot Universal Boot Loader

### Software Support

- Linux




See the [MEN website](#) for more information on supported operating system versions and drivers.

## 1.6 Product Identification

MEN user documentation may describe several different models and/or design revisions of the G52A. You can find information on the article number, the design revision and the serial number on a label affixed to the board.

- **Article number:** Indicates the product family and model. This is also MEN's ordering number. To be complete it must have 9 characters.
- **Revision number:** Indicates the design revision of the product.
- **Serial number:** Unique identification assigned during production.

*Figure 4. Product labels*





## 2 Getting Started

### 2.1 Configuring the Hardware

You should check your hardware requirements before installing the board in a system, since most modifications are difficult, or even impossible, to do once the board is mounted in a rack.

The following chapters provide an overview on configuration possibilities.

#### 2.1.1 microSD Card

The board is shipped without a microSD card. You should check your needs and install a suitable microSD card.




See the MEN website for ordering information:  
[www.men.de/products/g52a/#ord](http://www.men.de/products/g52a/#ord)

See [Chapter 3.7.1 microSD Card on page 28](#) for a detailed description.

##### 2.1.1.1 Inserting and Extracting a microSD Card on the G52A

To install a microSD card, please stick to the following procedure.

- » Power down your system and remove the G52A from the system.
- » Put the board on a flat surface.
- » Insert the microSD card into the slot with the contacts at the top.



- » Make sure that it clicks into place properly.
- » For extracting the card push it down and pull it out.

## 2.2 Connecting and Starting

You can use the following check list when installing the board in a system for the first time and with minimum configuration.

- » Power down the system.
- » Remove all boards from the CompactPCI Serial system.
- » Insert the G52A into the system slot of your CompactPCI Serial system, making sure that the backplane connectors are properly aligned.

Note: The system slot of every CompactPCI Serial system is marked by a  $\triangle$  triangle with a plus sign behind it on the backplane and/or at the front panel. It also has red guide rails.

- » Connect a terminal to the USB-to-UART interface at the front panel.



See the MEN website for a suitable service cable:  
[www.men.de/products/g52a/#ord](http://www.men.de/products/g52a/#ord)

Note: An FTDI driver must be installed on the PC your terminal is running on.



See the FTDI chip website for all available drivers:  
<http://www.ftdichip.com/FTDrivers.htm>

- » Set your terminal to the following protocol:
  - 115 200 baud data transmission rate
  - 8 data bits
  - 1 stop bit
  - No parity
- » Power up the system.
- » U-Boot will load and then display a command line.
- » Now you can make configurations in the U-Boot.

See [Chapter 4 U-Boot Firmware on page 37](#).

## 2.3 Troubleshooting at Start-up

If you have any problems at start-up of the G52A, you can check if the front-panel status LED gives an error flash code.

See [Chapter 3.3.3.1 Board Status LED on page 25](#).

You can also start the board with firmware default settings for troubleshooting.

See [Chapter 4 U-Boot Firmware on page 37](#) for a detailed description.

## 2.4 **Installing Operating System Software**

By default, no operating system is installed on the G52A.



- Please refer to the respective manufacturer's documentation on how to implement the operating system.
- See the MEN website for all available software:  
[www.men.de/products/g52a/#downl](http://www.men.de/products/g52a/#downl)

See [Chapter 4.2 Getting Started: Setting Up Your Operating System on page 37](#) for details on the first steps of how to get your operating system running with U-Boot.

## 2.5 **Installing Driver Software**

For a detailed description on how to install driver software, please refer to the respective documentation of the software package to be installed.



- See the MEN website for all available software:  
[www.men.de/products/g52a/#downl](http://www.men.de/products/g52a/#downl)

## 2.6 **Using the G52A under Linux**

This chapter describes how to install and use Linux software together with the G52A. A detailed step-by-step description is given where needed.

### 2.6.1 **Accessing Board Management Functions**

There are two ways to access board management functions, e.g., the board management controller (BMC), under Linux:

- Using MEN software tools for Linux.
- Using standard Linux I2C tools.

#### **More information on supported functions and hardware implementation**

- See [Chapter 3.3 Supervision and Management on page 24](#).
- See [Chapter 5.3 BMC API \(Application Programming Interface\) on page 55](#) for a detailed description of the BMC API.
- See [Chapter 5.2 I2C Devices on page 54](#).

#### 2.6.1.1 **MEN Tools**

MEN provides a number of MDIS software tools for accessing G52A functions via the SMBus, which are included in the G52A Linux board support package (BSP):

- `xm01bc_ctrl` is the tool for accessing the BMC
- `smb2_eetemp` is the tool for accessing the temperature sensor

In the following you can find an exemplary description of how to access the BMC:

- » Install the G52A Linux BSP.



See the G52A Linux BSP user manual for a detailed BSP description:  
[www.men.de/products/g52a/#doc](http://www.men.de/products/g52a/#doc)

- » Print a list of all possible parameters of the `xm01bc_ctrl` tool:

```
$ sudo xm01bc_ctrl <device name> <device name> is a place holder for the name  
of the device
```

```
Usage: xm01bc_ctrl [<opts>] <device> [<opts>]
```

```
Function: Control XM01BC PIC
```

```
Options:
```

```
device      device name  
-v          show voltage values  
-s          do voltage supervision (requires option -v)  
  
-r=0xdead  perform SW warm reset (!! dangerous !!)  
-R=0xdead  perform SW cold reset (!! dangerous !!)  
  
-e          show error counters  
-c          clear error counters  
-n          get number of error counters  
  
-f          show firmware revision  
-F          show firmware revision extended  
  
-w          show last reset reason  
-x          show last error  
-y          show power failure flag  
-z          clear failure registers  
  
-o          show operating hours counter  
-p          show power cycle counter  
  
-l          get LED state  
-L=<state> set LED state  
  
-u          get power resume mode  
-a          get EXT_PWR_OK resume mode  
-b          get RESET_IN mode  
  
-h          get hardware variant ID  
  
-q          exit QM-Mode (for production tests only)
```

```
(c) 2008 by MEN mikro elektronik GmbH
```

- » For example, if you want to look up the voltage values, use the following command:

```
$ sudo xm01bc_ctrl -v xm01bc_1
```

### 2.6.1.2 Standard Linux I2C Tools

Carry out the following steps to access the BMC.



This procedure is also applicable to other SMBus devices.

- » Find out the number of the SMBus the BMC is located on by listing the I2C devices:

```
$ sudo i2cdetect -l (small | not number 1)

[...]
```

i2c-x	smbus	SMBus adapter	SMBus adapter
[...]			

*For example:*

i2c-9	smbus	SMBus adapter	SMBus adapter
-------	-------	---------------	---------------

- » Look up the SMBus address of the BMC in [Chapter 4.1 SMBus Devices on page 42](#). In this example, the BMC address is 0x4D (7-bit notation).
- » Display the devices of the SMBus (i2c-9) to look for the BMC address 0x4D:

```
$ sudo i2cdetect -y 9

    0  1  2  3  4  5  6  7  8  9  a  b  c  d  e  f
00:                -- -- -- -- -- 08 -- -- -- -- --
10: -- -- -- -- -- -- -- -- -- -- -- -- -- -- 1f
20: 20 21 22 -- -- -- -- 27 -- -- -- -- -- -- --
30: -- -- 32 -- -- -- -- 37 -- -- -- -- -- -- --
40: -- -- -- -- 44 -- -- -- -- -- -- -- 4d -- --
50: -- -- -- -- -- 56 57 -- -- -- -- -- -- -- --
60: 60 -- -- -- -- -- -- -- -- -- -- -- -- -- --
70: 70 -- -- -- -- -- -- -- -- -- -- -- -- -- --
```

- » In this example, the BMC has the address 0x4D, i.e. it is located on SMBus number 9.
- » There might be several SMBuses in the list. If you do not find the BMC address on the first SMBus, list the devices on the other SMBuses. For SMBus 1 (i2c-1), for example, use this command:

```
$ sudo i2cdetect -y 1
```

- » When you have found out the address of the BMC and the number of the SMBus you can dump the registers of the BMC using this command:

```
$ sudo i2cdump -y 9 0x4d
```

- » Read out values using command *i2cget*:

```
$ sudo i2cget -y 9 0x4d
```

In the following you can find some examples showing how to use the watchdog:

- Setting the watchdog time to 10 seconds (0x64):

```
$ sudo i2cset -y 9 0x4d 0x14 0x64 w
```

- Enabling the watchdog (if it's not enabled inside the BIOS firmware):

```
$ sudo i2cset -y 9 0x4d 0x11 0x00
```

- Triggering the watchdog:

```
$ sudo i2cset -y 9 0x4d 0x13 0x00
```

See [Chapter 5.3 BMC API \(Application Programming Interface\)](#) on page 55 for a detailed description of the BMC API.

## 3 Functional Description



The BSP for the operating system may not support all the functions of the G52A. See the [MEN website](#) for more information on hardware support on the respective BSP product page.

### 3.1 Power Supply

The G52A is supplied via the backplane.

### 3.2 Processor Core

The G52A is equipped with a twelve-core NXP QorIQ T4240 processor, which includes twelve 64-bit Power Architecture e6500 cores.



See the [NXP website](#) for more information on the QorIQ T4xxx processor family.

The following CPU types are available:

- NXP QorIQ T4240, twelve cores, 1.5 to 1.8 GHz
- NXP QorIQ T4160, eight cores, 1.5 to 1.8 GHz (on request)
- NXP QorIQ T4080, four cores, 1.5 to 1.667 GHz (on request)

#### 3.2.1 Thermal Considerations

The power dissipation of G52A heavily depends on its processor and I/O configuration and on the workload.

Power dissipation of a G52A equipped with a high-end 45 W processor is up to 72 W (45 W for the high-end processor and 27 W for the rest of the board).

The G52A provides a very high computing power on a small space. For this reason, it is vital to provide sufficient airflow (2.5 m/s).

A suitable heat sink is provided to meet thermal requirements.



If you use any other heat sink than that supplied by MEN, or no heat sink at all, warranty on functionality and reliability of the G52A may cease. Please [contact MEN](#) if you have any questions or problems regarding thermal behavior.

### **3.3 Supervision and Management**

The G52A provides an intelligent board management controller (BMC) with the following main features:

- System watchdog
- Operating hours counter
- Power cycle counter
- Voltage supervision
- Error state logging

#### **3.3.1 Watchdog**

The watchdog device monitors the CPU board on operating system level. If enabled, the watchdog must be triggered by application software. If the trigger is overdue, the watchdog initiates a board reset and in this way can put the system back into operation when the software hangs.

The watchdog unit can be enabled or disabled, as required and the watchdog timeout can be set in 100-ms steps from 100 ms up to 1:49:10 (hh:mm:ss) - 65536 steps.

#### **3.3.2 Temperature Measurement**


The G52A uses a temperature device to measure the local CPU board temperature.

The G52A automatically shuts down when reaching the temperature 105°C.



### 3.3.3 Status LEDs

Table 1. General status LEDs

Appearance	Position	Label	Color	Function
	Front panel	<i>S</i>	Yellow	Board status LED
	Front panel	<i>H</i>	Blue	Hot-Swap LED
	Bottom side of PCB		Yellow	User LED
	Bottom side of PCB		Yellow	User LED

#### 3.3.3.1 Board Status LED

The yellow status LED shows G52A status messages. The LED is controlled by a GPIO pin of the board controller. It is switched on when the G52A firmware starts, switched off when the G52A is switched off.

During normal operation the LED can be switched on and off using software.

In case of an error, the LED displays the following error messages by repeatedly flashing *n* times and then pausing for one second:

Table 2. Error codes signaled by board management controller via LED flashes

Number of Flashes	Error
1	+3.3 V failure
2	Input voltage failure
3	External power supply failure
4	CPU too hot
5	G52A firmware timeout
>5	Internal error

### 3.3.3.2 Hot-Swap LED

The hot-swap LED signals the hot-swap status.

*Table 3. Hot-swap LED*

Hot-Swap LED	Description
Off	The hot-swap switch is closed.
Starts flashing	The hot-swap switch is opened while the system is running (start of hot-swap sequence).
Lights continuously	The system has been shut down (end of hot-swap sequence).
	The hot-swap switch is open during power-up. The board controller delays the power-up sequence until the hot-swap switch is closed.
Stops flashing	The hot-swap switch has been closed while the hot-swap sequence is in progress. The board controller no longer waits for system shutdown.

If the hot-swap switch is closed after system shutdown, the board controller initiates Power Resume.

### 3.3.4 Software Support

Supervision and management functions are accessible by software.

- See [Chapter 2.6 Using the G52A under Linux on page 19](#) for details on using MEN driver software.
- See the MEN website for all available software:  
[www.men.de/products/g52a/#downl](http://www.men.de/products/g52a/#downl)
- See [Chapter 5.3 BMC API \(Application Programming Interface\) on page 55](#) for a detailed documentation of the BMC API.

### 3.4 Reset

The G52A is equipped with a reset button which is recessed within the front panel and requires a tool, e.g. paper clip to be pressed, preventing the button from being inadvertently activated.

### 3.5 Real-Time Clock (RTC)

The G52A includes a real-time clock connected to the processor as a system RTC. The real-time clock device is connected to the CPU via SMBus.

For data retention during power off the RTC is backed up by a supercapacitor. The supercapacitor gives an autonomy of up to 96 hours when fully charged.

For retention of time/date data after a power off of more than 96 hours the RTC can optionally be backed by a battery.



See the [MEN website](#) for ordering information.

Due to the RTC's reduced current consumption, the data retention time supported by the supercapacitor or battery can be increased considerably compared to the RTC integrated in the CPU.

Please note that the real-time clock integrated in the processor is **not used**. Configuring the date and time through the means provided by the operating system **does not set** the system RTC.

You can set the system date and time through the U-Boot firmware.

If you use dedicated MEN driver software supporting the system RTC, you can use the functions provided there to set the system date and time also via software.



See the [MEN website](#) for downloads and documentation.

## 3.6 Memory

### 3.6.1 DRAM System Memory

The DRAM system memory of G52A is scalable.

### 3.6.2 Boot Flash

The boot Flash memory contains the U-Boot firmware. It can also contain an operating system image and application software.

See [Chapter 4.7.1 Boot Flash Memory Map on page 48](#).

## 3.7 Mass Storage

### 3.7.1 microSD Card

The G52A provides an onboard microSD card slot on the bottom side of the PCB. The slot supports the Secure Digital 2.0 specification (microSDHC) with a storage capacity of up to 32 GB.

The slot is ready-to-use.



See the [MEN website](#) for ordering information.

### 3.7.2 Serial ATA (SATA)

The G52A supports RAID operation.

#### 3.7.2.1 Connection

- See the CompactPCI Serial standard PICMG CPCI-S.0 for the exact position of the SATA ports on the rear I/O connectors.
- See [Chapter 3.11 CompactPCI Serial on page 34](#) for the position of the SATA interfaces in a CompactPCI Serial system.

#### 3.7.2.2 Using the G52A in a CompactPCI Serial Peripheral Slot

If the G52A is used in a peripheral slot, the SATA interfaces on the CompactPCI Serial connectors are switched off.

### 3.8 USB

The G52A supports:


- EHCI implementation

#### 3.8.1 Front Connection

Connector type:

- 4-pin USB Series A receptacle according to Universal Serial Bus Specification Revision 2.0
- Mating connector:  
4-pin USB Series A plug according to Universal Serial Bus Specification Revision 2.0

*Table 4. Pin assignment - USB 2.0*

	1	+5V
	2	USB_D-
	3	USB_D+
	4	GND

*Table 5. Signal mnemonics - USB 1.0/2.0*

Signal	Direction	Function
+5V	out	+5 V power supply
GND	-	Digital ground
USB_D+, USB_D-	in/out	USB lines, differential pair

#### 3.8.2 Rear Connection

- Refer to the CompactPCI Serial standard PICMG CPCI-S.0 for the exact position of the USB ports on the rear I/O connectors.
- See [Chapter 3.11 CompactPCI Serial on page 34](#) for the exact position of the USB ports in a CompactPCI Serial system.

##### 3.8.2.1 Using the G52A in a Peripheral Slot

If the G52A is used in a peripheral slot, the USB interface on the CompactPCI Serial connectors is switched off.

#### 3.8.3 USB-to-UART Interface

The USB signals of this interface are converted to UART signals using a bridge chip, e.g., when you connect a PC or other remote station using a USB port. The remote computer does not need a UART port.

In this way it can be used as a COM interface for terminal connection even without additional driver software.



See the MEN website for a service cable for USB:  
[www.men.de/products/g52a/#ord](http://www.men.de/products/g52a/#ord)

### 3.9 Ethernet

See [Figure 2, Board layout – top view on page 12](#) for the exact position of the Ethernet ports.

#### 3.9.1 Front Connection

##### 3.9.1.1 M12

*Table 6. Connector types – Ethernet M12*

Connector	Type
On G52A	8-pin M12 receptacle X-coded, e.g., Phoenix Contact SACC-CI-M12FSX-8CON-L90
Mating	8-pin M12 plug X-coded

*Table 7. Pin assignment – Ethernet (8-pin M12)*

		10GBASE-T/ 1000BASE-T	10/100BASE-T
	1	BI_DA+	TX+
	2	BI_DA-	TX-
	3	BI_DB+	RX+
	4	BI_DB-	RX-
	5	BI_DD+	
	6	BI_DD-	
	7	BI_DC-	
	8	BI_DC+	

##### 3.9.1.2 RJ45

*Table 8. Connector types – Ethernet (RJ45)*

Connector	Type
On G52A	Modular 8/8-pin receptacle according to FCC68
Mating	Modular 8/8-pin plug according to FCC68

*Table 9. Pin assignment – Ethernet (RJ45)*

		1000BASE-T/ 10GBASE-T	10/100BASE-T
	1	BI_DA+	TX+
	2	BI_DA-	TX-
	3	BI_DB+	RX+
	4	BI_DC+	-
	5	BI_DC-	-
	6	BI_DB-	RX-
	7	BI_DD+	-
	8	BI_DD-	-

### 3.9.2 Rear Connection

- Refer to the CompactPCI Serial standard PICMG CPCI-S.0 for the exact position of the Ethernet ports on the rear I/O connectors.
- See [Chapter 3.11 CompactPCI Serial on page 34](#) for the exact position of the Ethernet ports in a CompactPCI Serial system.

### 3.9.3 Signal Mnemonics

*Table 10. Signal mnemonics – Ethernet*

Signal	Direction	Function
BI_Dx+/-	in/out	Differential pairs of data lines for 1000BASE-T or 10GBASE-T
RX+/-	in	Differential pair of receive data lines for 10/100BASE-T
TX+/-	out	Differential pair of transmit data lines for 10/100BASE-T

### 3.9.4 Ethernet MAC Addresses



The unique MAC address is set at the factory and should not be changed. Any attempt to change this address may create node or bus contention and thereby render the board inoperable.

The naming of the interfaces may differ depending on the operating system. The MAC addresses on G52A are:

*Table 11. Ethernet MAC addresses*

Interface	Position	Base Address
X1	Upper front	0x 74 8F 4D 11 00 00
X2	Centre front	0x 74 8F 4D 11 80 00
X3	Lower front	0x 74 8F 4D 11 A0 00
1_ETH	CompactPCI Serial connector P6	0x 74 8F 4D 11 20 00
2_ETH	CompactPCI Serial connector P6	0x 74 8F 4D 11 40 00
3_ETH	CompactPCI Serial connector P6	0x 74 8F 4D 11 60 00

"74 8F 4D" is the MEN vendor code. The last six digits describe the range from which the addresses for the board are taken. The serial number is added by the last three digits in the range:

Serial number 42 (X1):  $0x0000 + 0x002A = 0x002A$ .



See [Chapter 1.6 Product Identification on page 16](#).



### 3.9.5 Ethernet Status LEDs

The G52A provides a total of six Ethernet status LEDs at the front panel, two for each Ethernet channel. They signal the link and activity status.

*Table 12. Ethernet status LEDs at front panel*

Appearance	Label	Color	Function
	[1:3]/A	Yellow	Activity LED <ul style="list-style-type: none"> <li>▪ On: Tx/Rx activity</li> <li>▪ Off: No activity</li> <li>▪ Blinking: Tx/Rx activity</li> </ul>
	[1:3]/L	Green	Linkup LED <ul style="list-style-type: none"> <li>▪ On: Link up</li> <li>▪ Off: No link</li> <li>▪ Blinking: n/a</li> </ul>

### 3.10 *PCI Express*

- Refer to the CompactPCI Serial standard PICMG CPCI-S.0 for the exact position of the PCI Express ports on the rear I/O connectors.
- See [Chapter 3.11 CompactPCI Serial on page 34](#) for the exact position of the PCI Express ports in a CompactPCI Serial system.

### 3.11 *CompactPCI Serial*



Refer to the CompactPCI Serial standard PICMG CPCI-S.0 for detailed information regarding the rear I/O connectors.

- CompactPCI Serial Specification PICMG CPCI-S.0 Revision 2.0: 2015; PCI Industrial Computers Manufacturers Group (PICMG) [www.picmg.org](http://www.picmg.org)
- Introduction to CompactPCI Serial on Wikipedia: [en.wikipedia.org/wiki/CompactPCI\\_Serial](http://en.wikipedia.org/wiki/CompactPCI_Serial)

#### 3.11.1 *Backplane Filling Order*

The CompactPCI Serial standard supports a maximum of 2 PCI Express x8 links (fat pipe), 6 PCI Express x4, 8 SATA, 8 USB and 8 Ethernet interfaces.

Table 13. CompactPCI Serial backplane filling order

System Slot 1	Fat Pipe Periph. Slot 2	Fat Pipe Periph. Slot 3	Periph. Slot 4	Periph. Slot 5	Periph. Slot 6	Periph. Slot 7	Periph. Slot 8	Periph. Slot 9
PCI Express	1	2	3	4	5	6	7	8
USB	1	2	3	4	5	6	7	8
Ethernet	1	2	3	4	5	6	7	8
SATA	8	7	6	5	4	3	2	1
<b>Implementation on the G52A</b>								
	PCI Express 3.x x4	PCI Express 2.x x4	PCI Express 2.x x2	PCI Express 2.x x4				
	USB 2.0							
	1GBASE-T Ethernet	1GBASE-T Ethernet	1GBASE-T Ethernet					
							SATA	SATA

### **3.11.2 Using the G52A as a Peripheral Board**

It is possible to use more than one G52A board within a CPCI-S.0 system to build a redundant system or a cluster with more processing power. The communication between the boards is done via Ethernet in this case and the other high-speed interfaces cannot be used. The G52A cannot be booted via SATA in such a configuration.

In peripheral mode the following interfaces available on the CPCI-S.0 connector are disabled by the board firmware automatically:

- USB
- SATA
- All control signals which are only available for system boards

The board firmware detects if the board is inserted in a peripheral slot by monitoring the *SYS\_EN#* pin on CompactPCI Serial connector P1.

## 4 U-Boot Firmware

### 4.1 General

U-Boot is the G52A firmware that is invoked when the system is powered on.

The basic tasks of U-Boot are:

- Initialize the CPU and its peripherals
- PCI configuration
- Provide debug/diagnostic features on the U-Boot command line
- Boot the operating system



- See the MEN website for the current U-Boot (patch file and complete binaries, i.e. prebuilt main U-Boot image):  
[www.men.de/products/g52a/#downl](http://www.men.de/products/g52a/#downl)
- U-Boot is open source software. The source code that the G52A U-Boot is based on is available on request. Please **contact MEN**.



The following description only includes product-specific features. See the **DENX U-Boot and Linux Guide (DULG)** available under [www.denx.de/wiki/DULG/WebHome](http://www.denx.de/wiki/DULG/WebHome) for a general description and in-depth details on U-Boot. (See Chapter 2.3 Availability for a PDF version.)

### 4.2 Getting Started: Setting Up Your Operating System

When U-Boot starts up for the first time, it does not know yet which operating system (OS) to load and normally stops the boot procedure by its prompt. If you don't see the U-Boot prompt, reset the G52A again and press any key during start-up.

You need to make the necessary settings first and then load a boot image, e.g., via network. The exact steps and settings depend on the operating system.



- See the documentation of the respective MEN board support package (BSP) for G52A for OS-specific details and examples:  
[www.men.de/products/g52a/#doc](http://www.men.de/products/g52a/#doc)
- See **Chapter 4.3.4.1 Boot Methods on page 42** for supported boot methods.

### 4.3 Interacting with U-Boot

U-Boot uses a shell similar to the Linux Hush shell with a command history and autocompletion support.

#### 4.3.1 Setting Up a Console Connection

To interact with U-Boot, you can use the USB-to-UART interface as a serial console port. You can select the active console by means of environment variables *stdin*, *stdout* and *stderr*.

U-Boot command *coninfo* lists all active consoles.

The default setting of the COM ports is 115 200 baud, 8 data bits, no parity, and one stop bit. You can set the baud rate through environment variable *baudrate*.

See [Table 17, U-Boot – Environment variables – Console on page 50](#) for a list of all console variables.

#### 4.3.2 Entering the U-Boot Command Line

During normal boot, you can abort the booting process by pressing any key during start-up.

You can use U-Boot environment variable *bootdelay* to configure the autoboot behavior.

If an autoboot time is set, U-Boot waits for this amount of seconds (measured from its beginning) before it starts the operating system, to give the user a chance to abort booting and enter the command line.

See [Table 15, U-Boot – Environment variables – OS boot on page 48](#).

### 4.3.3 User Interface Basics

#### 4.3.3.1 Help and Navigation

Use the *help* command to get a list of available commands.

Arrow keys "up" ↑ and "down" ↓ let you navigate in the command line history.

The <TAB> key autocompletes commands and variables.

You can press <CTRL> <c> to abort.

#### 4.3.3.2 Configuring Your System

Use environment variables to configure your system. They can be viewed using the *printenv* command. To set or add variables, you can use commands *editenv* and *setenv*. To save the changed parameters use *saveenv*.

Command *defenv* resets the environment variables to default values.

To display an environment variable, you can do the following:

```
=> printenv baudrate
baudrate=115200
```

To print all variables:

```
=> printenv
baudrate=115200
bootdelay=-1
...
```

Shell variable expansion:

```
=> echo "Server IP: ${serverip}"
Server IP: 192.1.1.22
```

To edit, modify the variable in the edit line and press <Enter>:

```
=> editenv ipaddr
edit: 192.1.1.023
```

To edit a variable directly:

```
=> setenv ipaddr 192.1.1.123
```

To delete a variable completely:

```
=> setenv ipaddr
```

Set all variables to default:

```
=> defenv
```

You need to save any changes made, otherwise they will be lost after the next reset:

```
=> saveenv
Saving Environment to Flash...
```

See [Chapter 4.7.2 Environment Variables on page 48](#) for a list of the G52A environment variables.

### 4.3.3.3 Working with Scripts and Applications

You can use scripts or stand-alone applications for more complex tasks. Scripts can be stored in environment variables and executed by the `run` command.

You can enter a sequence of commands using different separators:

- `;` separated = all commands are executed
- `&&` separated = next command is executed only if no error occurred
- `||` separated = next command is executed only if an error occurred

#### Simple Scripts using the Command Line

You can create a script using the command line, and you can store it in an environment variable:

- » Create script (i.e. store list of commands in a variable), for example:

```
=> setenv menu_script 'echo "1=Boot Linux"; echo "2=Boot Alternative OS"; echo "3=Memory Test"; askenv _number; if test ${_number} = 1; then run script_linux; elif test ${_number} = 2; then run script_altos; else mtest; fi'
```



See [www.denx.de/wiki/view/DULG/CommandLineParsing](http://www.denx.de/wiki/view/DULG/CommandLineParsing).

- » Save the script in an environment variable (optional):

```
=> saveenv
```

- » Execute the script:

```
=> run menu_script
```

#### Scripts using Source Files

For more complex scripts, you can write a text file on your host computer, convert it, load it into the G52A Flash and run it on the G52A from the source file. The following shows how an example script is created on a Linux host computer:



- » Write the script as a TXT file. In the example, we have written a file called *brd\_info.txt*:

```
# example U-Boot script (show board info)
#
# convert:
# mkimage -A ppc -O linux -T script -C none -a 0 -e 0 -n "board info
script" -d ./brd_info.txt ./brd_info.scr

echo
echo Version:
echo ----- \\c      # \\c = no new line
version
echo
echo Board:
echo ----- \\c
eepro
echo
clocks
echo
echo Network:
echo -----
echo Interface: ${ethact}
echo Target: ${ipaddr} (${ethaddr})
echo Server: ${serverip}
echo
echo binfo:
echo -----
binfo
echo
```

- » Convert the TXT script to *.scr* format, e.g., under Linux:

```
$ mkimage -A ppc -O linux -T script -C none -a 0 -e 0 -n "board info
script" -d /examples/brd_info.txt /tftpboot/brd_info.scr
```

- » Download the script via network using the U-Boot command line:

```
=> tftpboot 192.1.1.22:/tftpboot/brd_info.scr
```

- » Execute the script:

```
=> source ${loadaddr}
```

### 4.3.4 Booting an Operating System

The G52A U-Boot supports the standard commands for booting the supported operating systems.

You can completely configure how U-Boot boots the operating system through environment variables. Variables *bootargs* and *bootcmd* include the arguments to be set and commands to be executed at boot-up to start the operating system.



- See the documentation of the respective MEN board support package (BSP) for G52A for OS-specific details and examples: [www.men.de/products/g52a/#doc](http://www.men.de/products/g52a/#doc)
- See [Chapter 4.2 Getting Started: Setting Up Your Operating System on page 37](#).



Please remember to save the settings you have made in the environment variables using *saveenv*.

#### 4.3.4.1 Boot Methods

The following boot methods are supported and recommended for G52A.

##### OS Boot via Network

U-Boot command *tftpboot* allows loading of the operating system via Ethernet using the TFTP protocol. The following interfaces are supported:

- X1 front interface and all three rear interfaces

##### OS Boot via Mass Storage Devices

U-Boot allows loading of the operating system via the following mass storage devices:

- SATA
- microSD
- USB

The following U-Boot commands can be used for booting:

- *ext2load*
- *fatload*

The command to be used depends on the file system of the device.

##### OS Boot via Boot Flash

U-Boot allows loading of an operating system binary stored in the user space of the onboard boot Flash.

## 4.4 U-Boot Images

### 4.4.1 Images

U-Boot has one image for normal operation called "Image 1". There is a dedicated Image 1 for CompactPCI Serial system slots and peripheral slots.

See below, [Chapter 4.4.1.1 Boot Flash Memory Devices for CompactPCI Serial and Peripheral Slots on page 43](#).

U-Boot also has a fallback image. However, this is only intended for factory usage and is not automatically executed. If Image 1 fails, you can make use of the G52A's Flash memory set-up to repair the image.

See below, [Repairing Image 1 in Case of a Boot Failure](#).

#### 4.4.1.1 Boot Flash Memory Devices for CompactPCI Serial and Peripheral Slots

G52A has two separate but identically mapped Flash memory devices. One device contains the U-Boot images for booting the G52A in a CompactPCI Serial system slot, and the other is used when the board is located in a CompactPCI Serial peripheral slot.

By default, the G52A automatically uses the Flash memory device matching the slot type that the board is inserted in, i.e. system or peripheral slot.

One memory device is always selected, and any accesses to U-Boot settings or updates will be active on the selected memory device. U-Boot command `men_sw_spi` allows to switch between the two memory devices.

#### Repairing Image 1 in Case of a Boot Failure

If the G52A does not start up U-Boot Image 1, you should do the following to repair Image 1:

- » Power down your system.
- » Remove the G52A from the CompactPCI Serial slot it was inserted in.
- » Insert the G52A into a different slot:
  - If the former slot was the system slot, select a peripheral slot.
  - If the former slot was a peripheral slot, select the system slot.
- » Power up the system.

The G52A now boots from the respective other memory device.

- » Enter the U-Boot command line.
- » Use command `men_sw_spi` to change memory access back to the corrupted memory device:

```
=> men_sw_spi 0 to switch to system slot boot Flash device  
or  
=> men_sw_spi 1 to switch to peripheral slot boot Flash device
```

- » Update your corrupted Image 1 by a working image file:

See [Chapter 4.4.2 Updating U-Boot Image 1 on page 44](#).

#### 4.4.2 Updating U-Boot Image 1



**Updating the boot Flash may damage the G52A!  
Read the following instructions carefully.  
Please be aware that you do boot Flash updates at your own risk.**

You can update U-Boot Image 1 via network, mass storage or serial console. Do the following to update U-Boot:

- » Download the current U-Boot Image 1 update from the MEN website.



[www.men.de/products/g52a/#downl](http://www.men.de/products/g52a/#downl)

- » Unzip the downloaded file, e.g., *14g052a00.zip*, into a temporary directory on your host system or on a mass-storage device.
- » If you use a mass-storage device, change U-Boot environment variable *img\_name* to the binary file name, e.g.:

*For the system slot image:*

```
=> setenv img_name u-boot_std_sys_14g052a00.bin
```

*For the peripheral slot image:*

```
=> setenv img_name u-boot_std_per_14g052a00.bin
```

- » If you use a host system, change U-Boot environment variable *img\_path\_name* to the path and binary file name, e.g.:

*For the system slot image:*

```
=> setenv img_path_name /tftpboot/temp/u-boot_std_sys_14g052a00.bin
```

*For the peripheral slot image:*

```
=> setenv img_path_name /tftpboot/temp/u-boot_std_per_14g052a00.bin
```

- » If you use a serial console or network connection, connect your host computer to the G52A.
- » If you use a USB or other mass storage device, connect the device to the G52A.
- » Power on the G52A and enter the U-Boot command line.
- » Run the update script that applies in your case:

*Via network:*

```
=> run update_tftp
```

*Via USB:*

```
=> run update_usb
```

*Via serial console:*

```
=> run update_uart
```

- » If you need an update script for a mass-storage device other than USB, take the *update\_usb* script as a template and create a new, specific environment variable. Make sure to leave the Flash address as specified.

See Table 18, U-Boot – Environment variables – Other on page 50.

- » When the update procedure has completed, reset the G52A.

## 4.5 Updating User Data in the Boot Flash

You can write binary files to the user space in the boot Flash via network, a mass storage device, or a serial console connection. U-Boot provides commands specific for each medium to load a binary update file, and the following general commands to program the boot Flash:

- *sf*



**Updating the boot Flash may damage the G52A!  
Read the following instructions carefully.  
Please be aware that you do boot Flash updates at your own risk.**

See [Chapter 4.7.1 Boot Flash Memory Map on page 48](#) for the exact addresses and size of the user space.

### 4.5.1 Update via Network

You can use U-Boot command *tftpboot* to download the binary update file from a TFTP server in the network.

### 4.5.2 Update via Mass Storage Devices

You can also make a Flash update from a mass storage device, e.g., a USB Flash drive or plugged microSD card. The following U-Boot commands are supported to load the binary update file:

- *ext2load*
- *fatload*

### 4.5.3 Update via the Serial Console

U-Boot provides the *loady* tool to download a binary update file.

The terminal emulation program must be configured to start the upload via the "Ymodem" and send the required file.

Set the terminal emulation program to the following protocol:

- 115 200 baud
- 8 data bits
- 1 stop bit
- No parity
- No handshaking

#### 4.5.4 Performing an Update

To perform an update, e.g., of your operating system image inside the Flash, use the following procedure.

See [Chapter 4.4.2 Updating U-Boot Image 1 on page 44](#) for instructions on how to update the U-Boot code itself.

- » Make sure the size of your binary file is within the boundaries of the user address space and will be written to the correct address.

See [Chapter 4.7.1 Boot Flash Memory Map on page 48](#).

- » Download the update file to the G52A:

*Via network, e.g.:*

```
=> tftpboot ${loadaddr} ${serverip}:/path/file.bin
```

*Via mass storage, e.g., USB:*

```
=> usb start; fatload usb 0:1 ${loadaddr} /file.bin  
0:1 = device 0 partition 1
```

*Via serial console, e.g., with Y protocol:*

```
=> loady
```

- » Erase the part of the Flash that you want to update:

```
=> sf probe; sf erase <write address> +${filesize}  
<write address> is the update address, e.g., 0xffffffff
```

- » Write the file to Flash:

```
=> sf write ${loadaddr} <write address> ${filesize}
```

## 4.6 Diagnostic Tests

### 4.6.1 Power-On Self Tests

The G52A U-Boot includes a number of power-on self tests (POST). If a test fails, U-Boot stops booting and enters the command line.

You can use the *failbootcmd* environment variable to execute special commands in case of an error. The settings of *failbootcmd* will be executed also if the fallback U-Boot image is forced to load.

The following tests are executed at power-on:

- **Main memory test:** Tests the address and data bus of the main memory.<sup>1</sup>
- **MAC address test:** Verifies if Ethernet MAC addresses are available in EEPROM.

The **main memory test** may take up to 20 seconds. Therefore, the test runs only once when the G52A is powered up for the very first time during production. If the test was executed successfully, environment variable *memtest\_state* is set to *done*.

To force execution of a new main memory test, change environment variable *memtest\_state* to *run*, save the environment variables using *saveenv* and restart the G52A.

<sup>1</sup> Only the first 2 GB of memory are tested.

## 4.7 U-Boot Implementation on G52A

### 4.7.1 Boot Flash Memory Map

Note: The G52A has two boot Flash memory devices. The memory map below is identical for both devices.

See [Chapter 4.4.1.1 Boot Flash Memory Devices for CompactPCI Serial and Peripheral Slots](#) on page 43.

*Table 14. U-Boot – Boot Flash memory map*

Address Range	Size	Description
0x 0000 0000 – 0x 0003 FFFF	256 KB	RCW, PBL, SPL U-Boot
0x 0004 0000 – 0x 000F FFFF	768 KB	U-Boot binary, Image 1
0x 0010 0000 – 0x 0010 1FFF	8 KB	U-Boot environment, Image 1
0x 0010 2000 – 0x 0010 FFFF	56 KB	Reserved
0x 0011 0000 – 0x 0012 FFFF	128 KB	FMAN (FrameManager) firmware for networking functions
0x 0013 0000 – 0x 0018 FFFF	768 KB	U-Boot binary, fallback image; only for factory usage
0x 001F 0000 – 0x 001F 1FFF	8 KB	U-Boot environment, fallback image; only for factory usage
0x 001F 2000 – 0x 001F FFFF	56 KB	Reserved
0x 0020 0000 – 0x 0027 FFFF	512 KB	User Area 1
0x 0028 0000 – 0x 004F FFFF	2.5 MB	User Area 2
0x 0050 0000 – 0x 01FF FFFF	27 MB	User Area 3

### 4.7.2 Environment Variables

U-Boot uses environment variables stored in Flash to configure the target. The available variables are specific for the G52A.

See [Chapter 4.3.3.2 Configuring Your System](#) on page 39 for editing commands and examples.

*Table 15. U-Boot – Environment variables – OS boot*

Variable	Description	Default	Access
<i>bootargs</i>	Boot arguments when booting an OS image	The boot command will set <i>bootargs</i> .	r/w
<i>bootcmd</i>	Command string that is automatically executed after reset	echo "no boot command defined"	r/w
<i>bootdelay</i>	Delay before the default image is automatically booted, in seconds. Set to -1 to disable autoboot	-1	r/w
<i>bootfile</i>	Name of the image to load through command <i>tftpboot</i>	Empty	r/w



Variable	Description	Default	Access
<i>failbootcmd</i>	Code string to be executed in case of a boot failure, e.g., during power-on self tests.	<i>echo "POSTFAIL detected, no OS boot"</i>	r/w
<i>linux_path</i> <sup>1</sup>	Linux boot path and file used by default <i>bootcmd</i>	<i>/tftpboot/G052A/os_linux</i>	r/w
<i>linux_setargs</i> <sup>1</sup>	Used to set <i>bootargs</i> Default: <i>setenv bootargs root=/dev/ram rw console=ttyS0,\${baudrate}</i>		r/w
<i>linux_mmc</i> <sup>1</sup>	Example script for booting Linux via microSD	See U-Boot, <i>print linux_mmc</i>	r/w
<i>linux_tftp</i> <sup>1</sup>	Example script for booting Linux via network	See U-Boot, <i>print linux_tftp</i>	r/w
<i>linux_usb</i> <sup>1</sup>	Example script for booting Linux via USB	See U-Boot, <i>print linux_usb</i>	r/w
<i>os</i> <sup>1</sup>	Operating system to boot (e.g., <i>linux</i> , <i>vxworks</i> )	--- do not boot ---	r/w

Table 16. U-Boot - Environment variables - Network

Variable	Description	Default	Access
<i>ethact</i>	Controls which network interface is currently active; automatically set to current network interface Possible values: <ul style="list-style-type: none"> <li>▪ <i>dTSEC4</i> (X1)</li> <li>▪ <i>dTSEC1</i> (rear, 1_ETH)</li> <li>▪ <i>dTSEC2</i> (rear, 2_ETH)</li> <li>▪ <i>dTSEC3</i> (rear, 3_ETH)</li> <li>▪ not defined (empty)</li> </ul>	Empty	r/w
<i>ethaddr</i> <i>eth1addr</i> <i>eth2addr</i> <i>eth3addr</i> <i>eth4addr</i> <i>eth5addr</i>	MAC address of Ethernet interface (see <a href="#">Chapter 3.9.4 Ethernet MAC Addresses on page 32</a> ). You can pass a MAC address to the OS using the <i>cpenv</i> command.	<i>74:8f:4d:11:x0:00</i> <sup>1</sup>	r
<i>ethprime</i>	Primary Ethernet controller	<i>dTSEC4</i> (X1)	r/w
<i>gatewayip</i>	IP address of the gateway (router) to use	<i>192.1.1.22</i>	r/w
<i>hostname</i>	Target host name	Empty	r/w
<i>ipaddr</i>	IP address; needed for <i>tftpboot</i> command	<i>192.1.1.254</i>	r/w
<i>loadaddr</i>	Default load address for U-Boot commands	<i>0x01000000</i>	r/w
<i>netmask</i>	Subnet mask	<i>255.255.255.0</i>	r/w
<i>serverip</i>	TFTP server IP address; needed for <i>tftpboot</i> command	<i>192.1.1.22</i>	r/w
<i>user</i>	TFTP user name	Empty	r/w

<sup>1</sup> x stands for the base address of the respective channel.

Table 17. U-Boot – Environment variables – Console

Variable	Description	Default	Access
<i>baudrate</i>	Baud rate for serial console Possible values: 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200	115200	r/w
<i>stderr</i>	Standard error console Possible values: <i>serial</i>	<i>serial</i>	r/w
<i>stdin</i>	Standard input console Possible values: <i>serial</i>	<i>serial</i>	r/w
<i>stdout</i>	Standard output console Possible values: <i>serial</i>	<i>serial</i>	r/w

Table 18. U-Boot – Environment variables – Other

Variable	Description	Default	Access
<i>cust_env</i>	For factory use only	0	r
<i>dbg_env</i>	For factory use only	0	r
<i>hwconfig</i>	Describes the used hardware configuration	<i>hwconfig=fsl_ddr:ctrl_intlv=3way_4KB,bank_intlv=null;usb1:dr_mode=host,phy_type=utmi</i>	r
<i>img_path_name</i>	Image location and name of U-Boot Image 1 update file. Used in command <i>run update_tftp</i> .	<i>/tftpboot/G052A/u_boot/u-boot_std_sys_14G052A00.bin</i>	r/w
<i>img_path_name_fman</i>	Name of T4240 <i>fman</i> firmware update file. Used in command <i>run update_usb_fman</i> .	<i>fsl_fman_ucose_t4240_r2.0_106_4_15.bin</i>	r/w
<i>img_name</i>	Name of U-Boot update file. Used in command <i>run update_usb</i> .	<i>u-boot_std_sys_14G052A00.bin</i>	r/w
<i>memorytest_state</i>	State of start-up main memory test <ul style="list-style-type: none"> <li>▪ <i>run</i>: force memory test at next start-up</li> <li>▪ <i>done</i>: memory test successfully executed; test will not run at next start-up</li> </ul>	<i>run</i>	r/w
<i>mp_holdoff</i>	Setting for multi-processor usage	<i>n</i>	r/w
<i>pre_delay</i>	Delay time before release of external reset (n*100 ms; e.g., 0x05 = 500 ms)	0x05	r/w
<i>post_delay</i>	Delay time after release of external reset (n*100 ms; e.g., 0x0F = 1500 ms)	0x0F	r/w
<i>update_tftp</i>	Updates U-Boot Image 1 via network. See <a href="#">Chapter 4.4.2 Updating U-Boot Image 1 (page 44)</a> .	See U-Boot, <i>print update_tftp</i>	r/w
<i>update_uart</i>	Updates U-Boot Image 1 via serial console. See <a href="#">Chapter 4.4.2 Updating U-Boot Image 1 (page 44)</a> .	See U-Boot, <i>print update_uart</i>	r/w

Variable	Description	Default	Access
<i>update_usb</i>	Updates U-Boot Image 1 via USB. See <a href="#">Chapter 4.4.2 Updating U-Boot Image 1 (page 44)</a> .	See U-Boot, <i>print update_usb</i>	r/w
<i>update_usb_fman</i>	Updates the T4240 <i>fman</i> firmware image via USB. <b>This function is intended for updates with files provided directly from the processor manufacturer.</b> It works similarly to the other update functions, e.g., <i>update_usb</i> . See <a href="#">Chapter 4.4.2 Updating U-Boot Image 1 (page 44)</a> .	See U-Boot, <i>print update_usb_fman</i>	r/w

### 4.7.3 U-Boot Commands

You can access the full U-Boot command list using the *help* command (or the *?* alias). More detailed information is displayed if you enter *help <command>*. U-Boot supports auto completion using the *<TAB>* key.

The following table provides only the G52A-specific commands.

**Table 19.** U-Boot – G52A-specific commands

Command	Description
<i>bootu</i>	Boot special application image from memory (customer defined, not for general usage)
<i>cpenv</i>	Copy environment string to address (default is 0x5000), may be needed to forward some additional parameters to an OS without flat device tree support
<i>defenv</i>	Set environment variables to default values (use <i>saveenv</i> to store the changes)
<i>eeprod</i>	Display MEN production data
<i>macerase</i>	Reserved, for internal factory usage only
<i>macread</i>	Read all MAC addresses from EEPROM and display them
<i>macwrite</i>	Reserved, for internal factory usage only
<i>men_info</i>	Print register information (for debugging)
<i>men_sw_spi</i>	Switch boot Flash: select system or peripheral serial boot Flash See <a href="#">Chapter 4.4.1.1 Boot Flash Memory Devices for CompactPCI Serial and Peripheral Slots on page 43</a> .
<i>uptime</i>	Get time since time base reset, in milliseconds

### 4.7.4 Hardware Interfaces Not Supported by U-Boot

The standard G52A U-Boot does **not** support the following hardware interfaces:

- 10GBASE-T front interfaces (X2 and X3)

## 5 Hardware/Software Interface

This chapter is intended for software developers or board integrators who need deeper knowledge of the implementation details of the G52A interfaces and its internal connections.

### 5.1 PCI Express Root Port Interrupt Mapping

*Table 20. PCI Express Root Port Interrupt Mapping for Downstream Devices*

PCI Express Controller	CompactPCI Slot	INTx	IRQn
PCI Express 1	CPCI slot 2 (x4)	INTA#	-
		INTB#	IRQ1
		INTC#	IRQ2
		INTD#	IRQ3
PCI Express 2	CPCI slot 1 (x4)	INTA#	-
		INTB#	IRQ5
		INTC#	IRQ6
		INTD#	IRQ7
PCI Express 3	CPCI slot 4 (x4)	INTA#	-
		INTB#	IRQ9
		INTC#	IRQ10
		INTD#	IRQ11
PCI Express 4	CPCI slot 3 (x2)	INTA#	-
		INTB#	IRQ0
		INTC#	IRQ4
		INTD#	IRQ8

## 5.2 I2C Devices

Table 21. I2C devices

Bus	8-Bit Address	7-Bit Address	Function	MDIS Device Name
I2C1	0xA8	0x54	EEPROM	smb2_1ppc
	0x68	0x34	EEPROM: write protect	
I2C3	0xA2	0x51	Customer EEPROM	
I2C1	0x90	0x48	Temperature sensor for CPU diode with integrated temperature sensor for board temperature	smb2_1ppc
	0x64	0x32	System RTC (see also <a href="#">Chapter 3.5 Real-Time Clock (RTC) on page 27</a> )	
	0x9A	0x4D	Board Management Controller	
	0x80	0x40	VID Power Supply	
	0xD0	0x68	Clock Generator	



### Note on 8-Bit/7-Bit Addressing

- 8-bit addressing** is compliant to the Windows nomenclature. The last bit, which is used as the read/write bit, is added to the address (0 = write, 1 = read).  
 If you use MDIS driver software, use 8-bit addresses, with any OS.
- 7-bit addressing** is used, e.g., under Linux. A '0' is added at the beginning of the address so that all consecutive address bits are moved one bit to the right.  
 If you use standard I2C commands under Linux, use 7-bit addresses.

### 5.3 BMC API (Application Programming Interface)

The G52A uses a generic command interface for communication between the CPU (host) and the BMC. Application software uses command packets to communicate with the BMC.

The application software controls the BMC via I2C/SMBus. The device address is 0x4D (in 7-bit, non-shifted notation) or 0x9A/0x9B (in 8-bit, shifted notation, write/read).

#### 5.3.1 BMC Command Packets

##### 5.3.1.1 Command Packet Protocol

From a logical point of view, the command protocol has the following characteristics:

- Commands are always initiated by the host. The BMC never sends packets without the host requesting it to do so.
- Packets are either
  - unidirectional from host to BMC, without an answer from the BMC
  - bidirectional, with an answer from the BMC
- Each command has a unique identifier, consisting of the command opcode and a packet type:

*Table 22. BMC API – Packet types*

Packet Type	Description	Request Data Host > BMC	Response Data BMC > Host	Error Signaling
<i>PT_SB</i>	Send command only	None	No response	-
<i>PT_RBD</i>	Send command, get one data byte from BMC	None	1 byte	Response byte = 0xFF
<i>PT_WBD</i>	Send command, send one data byte to BMC	1 byte	No response	-
<i>PT_RWD</i>	Send command, get two data bytes from BMC	None	2 bytes	Response byte = 0xFFFF
<i>PT_WWD</i>	Send command, send two data bytes to BMC	2 bytes	No response	-

The packet types are directly mapped to the corresponding SMBus “bus protocols” as defined in the System Management Bus Specification.

**Table 23.** BMC API – Packet types mapping on SMBus

Packet Type	SMBus Protocol
<i>PT_SB</i>	Send byte
<i>PT_RBD</i>	Read byte
<i>PT_WBD</i>	Write byte
<i>PT_RWD</i>	Read word
<i>PT_WWD</i>	Write word

### 5.3.1.2 Watchdog Control Commands

**Table 24.** BMC API – Watchdog commands

Command	Packet Type	Opcode	Functional Description
<i>WDOG_ON</i>	<i>PT_SB</i>	0x11	Enable watchdog
<i>WDOG_OFF</i>	<i>PT_WBD</i>	0x12	Disable watchdog
<i>WDOG_TRIG</i>	<i>PT_SB</i>	0x13	Trigger watchdog
<i>WDOG_TIME_SET</i>	<i>PT_WWD</i>	0x14	Set watchdog timeout value
<i>WDOG_TIME_GET</i>	<i>PT_RWD</i>	0x14	Get watchdog timeout value
<i>WDOG_STATE_GET</i>	<i>PT_RBD</i>	0x17	Get watchdog state
<i>WDOG_ARM</i>	<i>PT_SB</i>	0x18	Arm watchdog and BIOS timeouts
<i>ARM_STATE</i>	<i>PT_RBD</i>	0x19	Get watchdog arming state

#### Command *WDOG\_ON*

<b>Opcode:</b> 0x11	<b>Packet Type:</b> <i>PT_SB</i>
---------------------	----------------------------------

#### Command *WDOG\_OFF*

<b>Opcode:</b> 0x12	<b>Packet Type:</b> <i>PT_WBD</i>							
<b>Bit</b>	<b>7</b>	<b>6</b>	<b>5</b>	<b>4</b>	<b>3</b>	<b>2</b>	<b>1</b>	<b>0</b>
<b>Data</b>	0x69							

#### Command *WDOG\_TRIG*

<b>Opcode:</b> 0x13	<b>Packet Type:</b> <i>PT_SB</i>
---------------------	----------------------------------



### Commands WDOG\_TIME\_SET and WDOG\_TIME\_GET

#### Command WDOG\_TIME\_SET

Opcode: 0x14					Packet Type: PT_WWD				
Bit	7	6	5	4	3	2	1	0	
Data 0	WD_TOUT (LSB)								
Data 1	WD_TOUT (MSB)								

#### Command WDOG\_TIME\_GET

Opcode: 0x14					Packet Type: PT_RWD				
Bit	7	6	5	4	3	2	1	0	
Data 0	WD_TOUT (LSB)								
Data 1	WD_TOUT (MSB)								
Bit Field		Description							
WD_TOUT		Trigger timeout, in steps of 100 ms <ul style="list-style-type: none"> <li>▪ 0x0001: 100 ms</li> <li>▪ 0x0002: 200 ms</li> <li>▪ ...</li> <li>▪ 0xFFFF: Error</li> </ul>							

#### Command WDOG\_STATE\_GET

Opcode: 0x17					Packet Type: PT_RBD				
Bit	7	6	5	4	3	2	1	0	
Data	WD_STATE								
Bit Field		Description							
WD_STATE		Watchdog state <ul style="list-style-type: none"> <li>▪ 0x00: Off</li> <li>▪ 0x01: On</li> <li>▪ 0xFF: Error</li> </ul>							

**Command WDOG\_ARM**

Opcode: 0x18	Packet Type: PT_SB
--------------	--------------------

**Command WDOG\_ARM\_STATE**

Opcode: 0x19							Packet Type: PT_RBD	
Bit	7	6	5	4	3	2	1	0
Data	ARM_STATE							
Bit Field		Description						
ARM_STATE		Watchdog arming state <ul style="list-style-type: none"> <li>▪ 0x00: Not armed</li> <li>▪ 0x01: Armed</li> <li>▪ 0xFF: Error</li> </ul>						

**5.3.1.3 Power Resume Mode Commands**

These commands allow configuring the behavior of the G52A in case the power is reapplied after a power failure and input voltages return to their allowed limits.

This setting is only used when the G52A is in Master mode. When the G52A is in Slave mode, the BMC always starts the power-up sequence.

See [Chapter 5.3.1.12 Board Controller Mode on page 70](#).

The setting is persistent, i.e. it is stored in non-volatile memory.

The default resume mode after factory programming is "On".

*Table 25. BMC API – Power resume mode commands*

Command	Packet Type	Opcode	Functional Description
RESUME_MODE_SET	PT_WBD	0x20	Set power resume mode
RESUME_MODE_GET	PT_RBD	0x20	Get power resume mode

*Table 26. BMC API – Power resume modes*

Resume Mode	System State at Power Loss	Resume Action
On	On	Start power-up sequence
	Off	Start power-up sequence
Off	On	Stay in S4/S5 state
	Off	Stay in S4/S5 state
Former	On	Start power-up sequence
	Off	Stay in S4/S5 state

S0 to S5 are the power states as defined in the ACPI specification, or an equivalent state



Please refer to the ACPI Specification for more details on the power states S0 to S5:  
Advanced Configuration and Power Interface Specification Version 6.1  
January, 2016  
Unified EFI Forum  
[uefi.org/specifications](http://uefi.org/specifications)

### Commands *RESUME\_MODE\_SET* and *RESUME\_MODE\_GET*

#### Command *RESUME\_MODE\_SET*

Opcode: 0x20		Packet Type: <i>PT_WBD</i>							
Bit	7	6	5	4	3	2	1	0	
Data	<i>RES_MODE</i>								

#### Command *RESUME\_MODE\_GET*

Opcode: 0x20		Packet Type: <i>PT_RBD</i>							
Bit	7	6	5	4	3	2	1	0	
Data	<i>RES_MODE</i>								
Bit Field	Description								
<i>RES_MODE</i>	Resume mode <ul style="list-style-type: none"> <li>▪ 0x00: Off</li> <li>▪ 0x01: On</li> <li>▪ 0x02: Former</li> </ul>								

### 5.3.1.4 External Power Supply Failure Mode

These commands allow configuring the behavior of the G52A upon assertion of an external power supply fail signal.

Modes:

- Ignore: Assertion of external power failure signal is completely ignored.
- Treat as error: Assertion of external power failure is treated as an error; i.e. event is counted as an error and G52A is reset.

The setting is persistent, i.e. it is stored in non-volatile memory.

The default external power supply fail signal mode after factory programming is "Ignore".

**Table 27.** BMC API – External power supply failure mode commands

Command	Packet Type	Opcode	Functional Description
EXT_PWR_FAIL_MODE_SET	PT_WBD	0x21	Set external power supply failure mode
EXT_PWR_FAIL_MODE_GET	PT_RBD	0x21	Get external power supply failure mode

#### Commands EXT\_PWR\_FAIL\_MODE\_SET and EXT\_PWR\_FAIL\_MODE\_GET

Command EXT\_PWR\_FAIL\_MODE\_SET

Opcode: 0x21					Packet Type: PT_WBD			
Bit	7	6	5	4	3	2	1	0
Data	EXT_PWR_FAIL_MODE							

Command EXT\_PWR\_FAIL\_MODE\_GET

Opcode: 0x21					Packet Type: PT_RBD			
Bit	7	6	5	4	3	2	1	0
Data	EXT_PWR_FAIL_MODE							
Bit Field	Description							
EXT_PWR_FAIL_MODE	External power supply failure mode <ul style="list-style-type: none"> <li>▪ 0x00: Ignore</li> <li>▪ 0x01: Treat as error</li> <li>▪ 0xFF: Error</li> </ul>							

### 5.3.1.5 Reset Signal Blocking

These commands allow blocking of G52A reset inputs. The setting is persistent, i.e. it is stored in non-volatile memory.

In a system with master and slave CPU boards, normally the slave boards will get a reset whenever the master board resets. With "Reset Signal Blocking" configuration it is possible to decide at runtime for the slave boards whether they should get a reset whenever the master board resets or whether the slave board should operate independently. Additionally with this functionality it is possible to disable external reset for the master board where needed.

The default mode after factory programming is "Reset enabled".

**Table 28.** BMC API – Reset signal blocking commands

Command	Packet Type	Opcode	Functional Description
RESET_IN_MODE_SET	PT_WBD	0x22	Set reset input mode
RESET_IN_MODE_GET	PT_RBD	0x22	Get reset input mode

#### Commands RESET\_IN\_MODE\_SET and RESET\_IN\_MODE\_GET

Command RESET\_IN\_MODE\_SET

Opcode: 0x22					Packet Type: PT_WBD			
Bit	7	6	5	4	3	2	1	0
Data	RESET_IN_MODE							

Command RESET\_IN\_MODE\_GET

Opcode: 0x22					Packet Type: PT_RBD			
Bit	7	6	5	4	3	2	1	0
Data	RESET_IN_MODE							
Bit Field	Description							
RESET_IN_MODE	Reset input mode <ul style="list-style-type: none"> <li>▪ 0x00: Reset enabled</li> <li>▪ 0x01: Reset masked</li> <li>▪ 0xFF: Error</li> </ul>							

### 5.3.1.6 External Power Supply Control

In Master mode, the BMC uses the EXT\_PS\_ON signal to switch the external power supply on and off. In Slave mode, the BMC does not control the EXT\_PS\_ON signal.

*Table 29. BMC API – External power supply control commands*

Command	Packet Type	Opcode	Functional Description
EXT_PS_ON_MODE_SET	PT_WBD	0x23	Set EXT_PS_ON mode
EXT_PS_ON_MODE_GET	PT_RBD	0x23	Get EXT_PS_ON mode

#### Commands EXT\_PS\_ON\_MODE\_SET and EXT\_PS\_ON\_MODE\_GET

Command EXT\_PS\_ON\_MODE\_SET

Opcode: 0x23		Packet Type: PT_WBD						
Bit	7	6	5	4	3	2	1	0
Data	EXT_PS_ON_MODE							

Command EXT\_PS\_ON\_MODE\_GET

Opcode: 0x23		Packet Type: PT_RBD						
Bit	7	6	5	4	3	2	1	0
Data	EXT_PS_ON_MODE							
EXT_PS_ON_MODE	External power supply on/off mode <ul style="list-style-type: none"> <li>▪ 0x00: Invalid</li> <li>▪ 0x01: Always</li> <li>▪ 0x02: Switched</li> <li>▪ 0xFF: Error</li> </ul>							

### 5.3.1.7 Software Reset

These commands allow performing CPU resets under application software control.

Different types of resets are available:

- *SW\_RESET* issues a “warm reset”.
- *SW\_COLD\_RESET* issues a “cold reset”.
- *SW\_RTC\_RESET* issues a “cold reset”, together with an RTC reset.

Resets will be performed by writing the data word 0xDEAD, see below.

*Table 30. BMC API – Software reset commands*

Command	Packet Type	Opcode	Functional Description
<i>SW_RESET</i>	<i>PT_WWD</i>	0x31	Initiate software reset (warm reset)
<i>SW_COLD_RESET</i>	<i>PT_WWD</i>	0x32	Initiate cold reset
<i>SW_RTC_RESET</i>	<i>PT_WWD</i>	0x35	Initiate cold reset combined with RTC reset

#### Command *SW\_RESET*

Opcode: 0x31					Packet Type: <i>PT_WWD</i>			
Bit	7	6	5	4	3	2	1	0
Data 0	0xAD							
Data 1	0xDE							

#### Command *SW\_COLD\_RESET*

Opcode: 0x32					Packet Type: <i>PT_WWD</i>			
Bit	7	6	5	4	3	2	1	0
Data 0	0xAD							
Data 1	0xDE							

#### Command *SW\_RTC\_RESET*

Opcode: 0x35					Packet Type: <i>PT_WWD</i>			
Bit	7	6	5	4	3	2	1	0
Data 0	0xAD							
Data 1	0xDE							

### 5.3.1.8 Power Button

These commands allow initiating power button events.

*Table 31. BMC API – Power button commands*

Command	Packet Type	Opcode	Functional Description
<i>PWRBTN</i>	<i>PT_WBD</i>	0x33	Perform pressing of power button
<i>PWRBTN_OVRD</i>	<i>PT_WBD</i>	0x34	Perform power button override, i.e. assert the power button for more than 4 seconds to initiate system shutdown

#### Command *PWRBTN*

Opcode: 0x33					Packet Type: <i>PT_WBD</i>			
Bit	7	6	5	4	3	2	1	0
Data	0x69							

#### Command *PWRBTN\_OVRD*

Opcode: 0x34					Packet Type: <i>PT_WBD</i>			
Bit	7	6	5	4	3	2	1	0
Data	0x69							



### 5.3.1.9 Voltage Supervision

The voltage supervision commands the customer application to monitor different voltages on the G52A.

*Table 32. BMC API – Voltage supervision commands*

Command	Packet Type	Opcode	Functional Description
VOLT_LOW(0)	PT_RWD	0x40	Get lower limit of +3.3 V (in mV)
VOLT_LOW(1)	PT_RWD	0x41	Get lower limit of +5 V (in mV)
VOLT_LOW(2)	PT_RWD	0x42	Get lower limit of +12 V (in mV)
VOLT_LOW(3)	PT_RWD	0x43	Get lower limit of +5 V standby (in mV)
VOLT_LOW(4)	PT_RWD	0x44	Get lower limit of battery voltage (in mV)
VOLT_HIGH(0)	PT_RWD	0x50	Get upper limit of +3.3 V (in mV)
VOLT_HIGH(1)	PT_RWD	0x51	Get upper limit of +5 V (in mV)
VOLT_HIGH(2)	PT_RWD	0x52	Get upper limit of +12 V (in mV)
VOLT_HIGH(3)	PT_RWD	0x53	Get upper limit of +5 V standby (in mV)
VOLT_HIGH(4)	PT_RWD	0x54	Get upper limit of battery voltage (in mV)
VOLT_ACT(0)	PT_RWD	0x60	Get actual value of +3.3 V (in mV)
VOLT_ACT(1)	PT_RWD	0x61	Get actual value of +5 V (in mV)
VOLT_ACT(2)	PT_RWD	0x62	Get actual value of +12 V (in mV)
VOLT_ACT(3)	PT_RWD	0x63	Get actual value of +5 V standby (in mV)
VOLT_ACT(4)	PT_RWD	0x64	Get actual value of battery voltage (in mV)
NUM_VOLTS	PT_RBD	0x8E	Get number of supervised voltages

#### Command VOLT\_LOW(x)

Opcode: 0x40 + x					Packet Type: PT_RWD				
Bit	7	6	5	4	3	2	1	0	
Data 0	Lower limit of voltage x (LSB)								
Data 1	Lower limit of voltage x (MSB)								

#### Command VOLT\_HIGH(x)

Opcode: 0x50 + x					Packet Type: PT_RWD				
Bit	7	6	5	4	3	2	1	0	
Data 0	Upper limit of voltage x (LSB)								
Data 1	Upper limit of voltage x (MSB)								

**Command VOLT\_ACT(x)**

Opcode: 0x60 + x				Packet Type: PT_RWD				
Bit	7	6	5	4	3	2	1	0
Data 0	Actual value of voltage x (LSB)							
Data 1	Actual value of voltage x (MSB)							

**Command NUM\_VOLTS**

Opcode: 0x8E				Packet Type: PT_RBD				
Bit	7	6	5	4	3	2	1	0
Data	Number of supervised voltages							

### 5.3.1.10 Error Counters

The error counter commands allow querying and clearing error counters.

The BMC provides error counters for each type of error that can occur. Using this information, the application software can determine how often certain errors have occurred, but it is not possible to determine the chronological order of the errors.

You can determine the actual number of error counters using *NUM\_ERR\_CNTRS*, up to a theoretical maximum of 255 error counters.

All counters are set to zero during factory programming or using command *ERR\_CNT\_CLR*.

**Table 33.** BMC API – Error counters

Counter	Error Condition / Error Clearing
1	External BMC watchdog timeout (application software timeout)
2	Internal BMC watchdog timeout
3	Internal brown-out (BMC undervoltage)
4	External power failure
5	BIOS life sign timeout
6	Processor too hot
7	Shutdown while too hot
8	Internal power failure
9	Handshake timeout
10	Platform reset timeout
11	Error cleared using system reset
12	Error cleared using power cycling
13	Error cleared using power cycling with resume reset
14	Error cleared using power cycling with RTC reset
15	Error could not be corrected

**Table 34.** BMC API – Error counter commands

Command	Packet Type	Opcode	Functional Description
<i>ERRCNT_01</i>	<i>PT_RBD</i>	0x70	Get error counter 1
<i>ERRCNT_xx</i>		0x70 + x	Get error counter xx
<i>ERRCNT_15</i>		0x7E	Get error counter 15
<i>ERR_CNT_CLR</i>	<i>PT_WBD</i>	0x7F	Clear error counters
<i>NUM_ERR_CNTRS</i>	<i>PT_RBD</i>	0x8D	Get number of error counters

#### Command *ERRCNT\_xx* (1 to 15)

Opcode: 0x70 + x		Packet Type: <i>PT_RBD</i>						
Bit	7	6	5	4	3	2	1	0
Data	Value of error counter number xx							

**Command ERRCNT\_xx (16 to 32)**

Opcode: 0xB0 + x				Packet Type: PT_RBD				
Bit	7	6	5	4	3	2	1	0
Data	Value of error counter number xx							

**Command ERR\_CNT\_CLR**

This command clears all error counters.

Opcode: 0x7F				Packet Type: PT_WBD				
Bit	7	6	5	4	3	2	1	0
Data	0x69							

**Command NUM\_ERR\_CNTRS**

Opcode: 0x8D				Packet Type: PT_RBD				
Bit	7	6	5	4	3	2	1	0
Data	Number of error counters							

### 5.3.1.11 Firmware Revision

The firmware revision commands allow querying the separate parts of the BMC firmware revision.

*Table 35. BMC API – Firmware version commands*

Command	Packet Type	Opcode	Functional Description
GETREV_WORD0	PT_RWD	0x80	Get firmware revision major part
GETREV_WORD1	PT_RWD	0x81	Get firmware revision minor part
GETREV_WORD2	PT_RWD	0x82	Get firmware revision maintenance part
GETREV_WORD3	PT_RWD	0x83	Get firmware revision build part
GETREV_WORD4	PT_RWD	0x84	Get firmware revision verification marker

#### Command GETREV\_WORD0

Opcode: 0x80		Packet Type: PT_RWD							
Bit	7	6	5	4	3	2	1	0	
Data 0	Firmware Revision Major Part (LSB)								
Data 1	Firmware Revision Major Part (MSB)								

#### Command GETREV\_WORD1

Opcode: 0x81		Packet Type: PT_RWD							
Bit	7	6	5	4	3	2	1	0	
Data 0	Firmware Revision Minor Part (LSB)								
Data 1	Firmware Revision Minor Part (MSB)								

#### Command GETREV\_WORD2

Opcode: 0x82		Packet Type: PT_RWD							
Bit	7	6	5	4	3	2	1	0	
Data 0	Firmware Revision Maintenance Part (LSB)								
Data 1	Firmware Revision Maintenance Part (MSB)								

#### Command GETREV\_WORD3

Opcode: 0x83		Packet Type: PT_RWD							
Bit	7	6	5	4	3	2	1	0	
Data 0	Firmware Revision Build Part (LSB)								
Data 1	Firmware Revision Build Part (MSB)								

**Command GETREV\_WORD4**

Opcode: 0x84				Packet Type: PT_RWD				
Bit	7	6	5	4	3	2	1	0
Data 0	Firmware Revision Verification Marker (LSB)							
Data 1	Firmware Revision Verification Marker (MSB)							

**5.3.1.12 Board Controller Mode**

This command allows determining if the CPU is operated as a master or slave.

*Table 36. BMC API – Board controller mode command*

Command	Packet Type	Opcode	Functional Description
BOARD_MODE	PT_RBD	0x8B	Get board controller mode (Master/ Slave)

**Command BOARD\_MODE**

Opcode: 0x8B				Packet Type: PT_RBD				
Bit	7	6	5	4	3	2	1	0
Data	BOARD_CTRL_MODE							
Bit Field	Description							
BOARD_CTRL_MODE	Board controller mode <ul style="list-style-type: none"> <li>▪ 0x00: Invalid</li> <li>▪ 0x01: Master</li> <li>▪ 0x02: Slave</li> <li>▪ 0xFF: Error</li> </ul>							

### 5.3.1.13 Geographical Address

Table 37. BMC API – Backplane slot geographical address command

Command	Packet Type	Opcode	Functional Description
CPCI_SLOT_ADDRESS	PT_RBD	0x8C	Get CompactPCI peripheral slot address

#### Command SLOT\_ADDRESS

Opcode: 0x8C					Packet Type: PT_RBD			
Bit	7	6	5	4	3	2	1	0
Data	SLOT_ADDRESS							
Bit Field		Description						
SLOT_ADDRESS		CompactPCI backplane slot geographical board address <ul style="list-style-type: none"> <li>▪ 0x00 – 0x07: Information from GA[2:0] backplane pins</li> <li>▪ 0xFF: Error</li> </ul>						

### 5.3.1.14 Hardware Board Type

This command allows the BMC to query the board type, i.e. a unique ID that MEN assigns to each hardware board the generic BMC is implemented on. The board type is programmed into the BMC during production. The setting is persistent, i.e. is stored in a non-volatile memory.

#### Command HW\_BOARD\_GET

Opcode: 0x8F					Packet Type: PT_RWD			
Bit	7	6	5	4	3	2	1	0
Data 0	BOARD (LSB)							
Data 1	BOARD (MSB)							
Bit Field		Description						
BOARD		Unique MEN board ID						

### 5.3.1.15 Last Error

This command allows querying the last error.

*Table 38. BMC API – Last error command*

Command	Packet Type	Opcode	Functional Description
ERR_LAST	PT_RBD	0x90	Get last error

#### Command ERR\_LAST

Opcode: 0x90					Packet Type: PT_RBD			
Bit	7	6	5	4	3	2	1	0
Data	LAST_ERR_CODE							
Bit Field	Description							
LAST_ERR_CODE	Last error <ul style="list-style-type: none"> <li>▪ 0x00: Initial value; no error was registered by the BMC since the Last Error Register was cleared</li> <li>▪ 0x01: +3.3 V voltage failure</li> <li>▪ 0x02: Input voltage failure</li> <li>▪ 0x03: External power supply failure</li> <li>▪ 0x04: CPU too hot</li> <li>▪ 0x05: BIOS life sign timeout</li> <li>▪ 0x06: System reset timeout</li> <li>▪ 0x07: Platform reset failure</li> <li>▪ 0x08: Chipset handshake failure</li> <li>▪ 0x09: System power OK failure</li> <li>▪ 0xFF: Error</li> </ul>							



### 5.3.1.16 Power Failure Flags

This command allows querying the power failure flags of the G52A.

*Table 39. BMC API – Power failure flags command*

Command	Packet Type	Opcode	Functional Description
ERR_PWR_FLAGS	PT_RBD	0x91	Get power failure flags

#### Command ERR\_PWR\_FLAGS

Whenever a power failure occurs, the respective flag is set to 1 until the Power Failure Flag Register is cleared.

Opcode: 0x91					Packet Type: PT_RBD			
Bit	7	6	5	4	3	2	1	0
Data	BATT	-	EXT	SYS_PWROK	12V	5V_STDBY	5V	33V
Bit Field	Description							
Initial Value	0x00: No power failure was registered by the BMC since the Power Failure Flag Register was cleared.							
BATT	Battery failure							
EXT	External power supply failure							
SYS_PWROK	System power OK failure							
12V	+12 V input voltage failure							
5V_STDBY	+5 V standby voltage failure							
5V	+5 V input voltage failure							
33V	+3.3 V voltage failure							

### 5.3.1.17 Reset Reason

This command allows querying the reason of the last reset. The BMC maintains a Reset Reason Register that stores the reason for the last reset issued by the BMC.

*Table 40. BMC API – Reset reason command*

Command	Packet Type	Opcode	Functional Description
ERR_RST_RSN	PT_RBD	0x92	Get reason of last reset

#### Command ERR\_RST\_RSN

Opcode: 0x92					Packet Type: PT_RBD			
Bit	7	6	5	4	3	2	1	0
Data	RST_REASON							
Bit Field	Description							
RST_REASON	Reason of last reset <ul style="list-style-type: none"> <li>▪ 0x00: Initial value; no reset was issued by the BMC since the Reset Reason Register was cleared</li> <li>▪ 0x01: Regular reset</li> <li>▪ 0x02: External BMC watchdog timeout (application software timeout)</li> <li>▪ 0x03: Internal BMC watchdog timeout</li> <li>▪ 0x04: Internal brown-out reset (BMC undervoltage)</li> <li>▪ 0x05: External reset</li> <li>▪ 0x06: Platform reset</li> <li>▪ 0x07: Software warm reset</li> <li>▪ 0x08: Software cold reset</li> <li>▪ 0x09: Software cold reset with RTC reset</li> <li>▪ 0x0A: Power failure</li> <li>▪ 0x0B: Chipset handshaking timeout</li> <li>▪ 0x0C: PLT_RST timeout</li> <li>▪ 0x0D: BIOS life sign timeout</li> </ul>							

### 5.3.1.18 Clear Error Registers

This command allows clearing the Reset Reason Register, Last Error Register and Power Failure Flag Register, collectively called 'error registers'.

*Table 41. BMC API – Clear error registers command*

Command	Packet Type	Opcode	Functional Description
ERR_REG_CLR	PT_WBD	0x9F	Clear error registers

#### Command ERR\_REG\_CLR

Opcode: 0x9F					Packet Type: PT_WBD			
Bit	7	6	5	4	3	2	1	0
Data	0x69							

### 5.3.1.19 Power Cycle Counter

The power cycle counter counts the number of power cycles of the external power supply, i.e. the number of times the system changes from S5 into S0 state. S0 to S5 are the power states as defined in the ACPI specification, or an equivalent state



Please refer to the ACPI Specification for more details on the power states S0 to S5:  
Advanced Configuration and Power Interface Specification Version 6.1  
January, 2016  
Unified EFI Forum  
[uefi.org/specifications](http://uefi.org/specifications)

The counter is set to zero during factory programming.

*Table 42. BMC API – Power cycle counter command*

Command	Packet Type	Opcode	Functional Description
PWRCYCL_CNT	PT_RWD	0x93	Get power cycle counter

#### Command PWRCYCL\_CNT

Opcode: 0x93					Packet Type: PT_RWD			
Bit	7	6	5	4	3	2	1	0
Data 0	PWR_CYCLES (LSB)							
Data 1	PWR_CYCLES (MSB)							
Bit Field		Description						
PWR_CYCLES		Number of power cycles on the external power supply						

### 5.3.1.20 Operating Hours Counter

This command allows querying the operating hours counter. The operating hours counter counts the number of hours and minutes the board has been (at least partly) powered on, i.e. when the system is in S3 or S0 state.

S0 to S5 are the power states as defined in the ACPI specification, or an equivalent state



Please refer to the ACPI Specification for more details on the power states S0 to S5:  
Advanced Configuration and Power Interface Specification Version 6.1  
January, 2016  
Unified EFI Forum  
[uefi.org/specifications](http://uefi.org/specifications)

The counter is set to zero during factory programming.

*Table 43. BMC API – Operating hours counter command*

Command	Packet Type	Opcode	Functional Description
OP_HRS_CNT	PT_RWD	0x94	Get Operating Hours Counter

#### Command OP\_HRS\_CNT

Opcode: 0x94		Packet Type: PT_RWD							
Bit	7	6	5	4	3	2	1	0	
Data 0	OP_TIME (LSB)								
Data 1	OP_TIME (MSB)								
Bit Field		Description							
OP_TIME		Number of hours the board has been powered on							

### 5.3.1.21 Status LED Control

This command allows controlling status LEDs, depending on implementation on the product.

*Table 44. BMC API – Status LED control command*

Command	Packet Type	Opcode	Functional Description
<i>LED_CTRL_SET</i>	<i>PT_WBD</i>	0xA0	Set LED state
<i>LED_CTRL_GET</i>	<i>PT_RBD</i>	0xA0	Get LED state

#### Command *LED\_CTRL\_SET*

Opcode: 0xA0					Packet Type: <i>PT_WBD</i>			
Bit	7	6	5	4	3	2	1	0
Data	-				<i>USR2</i>	<i>USR1</i>	<i>HTSWP</i>	<i>STA</i>

#### Command *LED\_CTRL\_GET*

Opcode: 0xA0					Packet Type: <i>PT_RBD</i>			
Bit	7	6	5	4	3	2	1	0
Data	-				<i>USR2</i>	<i>USR1</i>	<i>HTSWP</i>	<i>STA</i>
Bit Field		Description						
<i>USR2:1</i>		User outputs 1 and 2						
<i>HTSWP</i>		Hot swap LED						
<i>STA</i>		Status LED at front panel						

### 5.3.2 Example BMC API Usage

See [Chapter 2.6.1 Accessing Board Management Functions on page 19](#) for how to access board management functions under Linux.

## 6 Maintenance

### 6.1 Optional Lithium Battery



This board might contain a lithium battery. There is a danger of explosion if the battery is incorrectly replaced!

- Replace only with the same or equivalent type.
- Manufacturer: Renata
- Type: CR1025
- Capacity: 30 mAh
- The battery has to be UL listed.



Used batteries have to be disposed of according to the local regulations concerning the disposal of hazardous waste.

Figure 5. Position of optional lithium battery on G52A

