

COMPONENTS AND ACCESSORIES

FRONT PANELS AND HANDLES

Extractor handle type I and type II



- Suitable for flat front panels/U-channel front panels
- With removal function
- May be used in combination with horizontal rails with 10 mm extension.

Supply includes

Assembly parts

Note

With 3 U, only one extractor handle is required.

1 Type I extractor handle, 15 mm


Colour	Packs of	Order No.
Grey	1	3685.587
Black	1	3685.589

2 Type II extractor handle, 30 mm

Colour	Packs of	Order No.
Grey	1	3685.588
Black	1	3685.590

+ Accessories

Identification strips for extractor handles, see page 169



Injector/extractor handle type IV



Handles with micro-switch

For inserting and removing connectors with a large number of pins.

- Insertion/removal function
- Integral microswitch for "live insertion" applications
- Self-activation of the micro-switch during insertion/removal
- ESD pin to dissipate static charges before contacting the connectors and for precise positioning of the board type plug-in unit
- Keyable
- Integral PCB attachment
- Self-locking
- Bayable

Handle without micro-switch

Description see above.
Micro-switch may be retrofitted.

Supply includes

1 handle without or with micro-switch, assembly parts

Note

- Insertion only when used with front horizontal rails, with 10 mm extension see page 133 ff.
- With 3 U front panels, only one extractor handle is required

Handles with micro-switch

Colour	Installation	Packs of	Order No.
Grey	Top	1	3686.905
Grey	Bottom	1	3686.904
Black	Top	1	3686.907
Black	Bottom	1	3686.906

Handle without micro-switch

Colour	Installation	Packs of	Order No.
Grey	Top	1	3686.901
Grey	Bottom	1	3686.900
Black	Top	1	3686.903
Black	Bottom	1	3686.902

+ Accessories

Keys, see page 159
Keyable guide rails, see page 156
Micro-switches, see page 171
Connector pin for baying, see page 170

