

COMPONENTS AND ACCESSORIES

FRONT PANELS AND HANDLES

Connection pin for injector/extractor handles



For injector/extractor handles, types IV, IVs and VII

The connection pin can be used to connect injector/extractor handles, types IV, IVs and VII.

Material

Steel

Packs of	Order No.
20	3685.319

Injector/extractor handle type VII



Plastic

For inserting and removing connectors with a large number of pins. This handle was specifically designed for use in telecom applications.

- Insertion/removal function
- Optionally with 1/2 HP offset PCB attachment, e. g. for component mounting on both sides
- Minimum front space requirements, due to foldup handle
- Optional integral micro-switch for "live insertion" applications
- ESD pin to dissipate static charges prior to making contact with the connectors and for precise positioning of the board type plug-in unit
- Keyable
- Large labelling area on the front

Material

Plastic

Supply includes

Assembly parts

Note

- Insertion only when used with front horizontal rails, with 10 mm extension see page 133 ff.

Handles without off set

Installation	Packs of	Order No.
Top	1	3688.784
Bottom	1	3688.785

Handles with 1/2 HP offs et

Installation	Packs of	Order No.
Top	1	3688.780
Bottom	1	3688.781

+ Accessories

Keys, see page 159
Keyable guide rails with 1/2 HP offset, see page 156
Micro-switches, see page 171
Connector pin for buying, see page 170

